

Serial Port Protocol

Protocol generated time: 2022年08月11日 00:03

Product information


Product name: Door Sensor

Product ID: omgfbw7apr3rtob8

Product functions:

dpID	Function name	Data transmission type	Data type	Function attribute	Remarks
1	Door Sensor	Only report	bool		
3	Battery level state	Only report	enum	Enumerated values: low, middle, high	

Tuya Wi-Fi general serial port protocol is a customized protocol for Wi-Fi modules of Tuya. It is mainly used for serial port communication between Tuya Wi-Fi modules and other MCU serial ports. The architecture diagram is shown as follows.



Points for attention during development are shown as follows:

- The whole protocol applies to devices that use Wi-Fi modules and cannot use external power supply. Power-off management is especially important during MCU program development. Under the precondition that functions can be completed, try to reduce the power-on duration of Wi-Fi modules. This is a key point to reduce power consumption. The control flowchart of data uploading is provided. You can select functions in the protocol according to your device features. During development, you can adjust relevant control logics as needed in a real-time way.
- Many devices can be used normally even when Wi-Fi function is disabled. Due to various reasons, users might not use the Wi-Fi function when they receive the device. In this case, we can design a physical button or relevant options for the device, in order not to power on the Wi-Fi module and cause electrical energy loss. Only when the user enables the button or option, and when the data changes, MCU will power on the Wi-Fi module to transfer relevant data.

Serial communication convention


- Baud: 9600
- Data bit: 8
- Parity check: None
- Stop bit: 1
- Data flow control: None
- MCU: Micro Controller Unit. MCU is connected to Tuya modules through serial ports. Regarding the protocol design, interaction of all packets is designed as full-duplex communication.

Frame format description

Field	Length (byte)	Description
Header	2	It is fixed as 0x55aa.
Version	1	It is used for upgrade and extension.
Command word	1	Specific frame type.
Data length	2	Big-endian.
Data	N	/
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder.

Note:


- All data greater than one byte shall be transmitted with big-endian mode.
- All examples in the protocol use hexadecimal data.
- The packets sent by Wi-Fi module time out after 1 second. The resend mechanism will resend three packets.
- Generally, the same command word adopts synchronous sending and receiving mechanism. One party sends a command, and the other party responds. If the sender fails to receive the correct response packet within the stipulated period, the transmission times out, as shown in the following figure.



Note: For specific communication mode, see the chapter "Protocol details".

- MCU status is reported in a synchronous way. "Command word" of reporting MCU status is y, as shown in the following figure.

MCU statistical data report:



Status data unit

Note:

- Data point command/status data unit is shown as follows:

Data segment	Length (byte)	Description
dpid	1	Data point serial number.
type	1	Specific data type of a data point on the IoT console. For more information, see the description of the type field.
len	2	Number of bytes of the value corresponding to length. For more information, see the description of the type field.
value	1/2/4/N	Expressed with hex, and adopt big-endian transmission when there are more than 1 byte.

Description of the type field:

type	Type	Length (byte)	Description
0x00	raw	N	Corresponding to raw data point (module pass-through).
0x01	bool	1	Value range: 0x00/0x01.
0x02	value	4	Corresponding to int type, which is expressed with big-endian.
0x03	string	N	Corresponding to specific string.
0x04	enum	1	Enumeration type, ranging from 0 to 255.
0x05	bitmap	1/2/4	Expressed with big-endian when there are more than 1 byte.

- For data point command/status data unit, except "raw" type, all other types belong to "obj" type data point.
- "Status data" can contain "command data units" of multiple data points.

Protocol details

Query product information

Note:

- Product ID: corresponding to product ID (PID) of Tuya IoT console. It is generated by Tuya cloud developer platform to record product information in the cloud.
- Product information consists of product ID (PID) and MCU software version.
- Define the format of MCU software version No.: dot-decimal notation, "x.x.x" (0<=x<=99), x is decimal digit.

For example, the module sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x01

Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

For example, the module sends the following command:

55 aa 00 01 00 00 00

MCU returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x01
Data length	2	N
Data	N	{"p": "vHXEcqntLpkAl***", "v": "1.0.0"}
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

For example, {"p": "vHXEcqntLpkAl***", "v": "1.0.0"}

p represents product ID, vHXEcqntLpkAl***, which is the product ID created by the user on the Tuya IoT console.

v represents MCU version number, which is 1.0.0.

MCU returns example information:

**55 aa 00 01 00 24 7b 22 70 22 3a 22 76 48 58 45 63 71 6e 74 4c 70 6b 41 6c 4f 73
79 22 2c 22 76 22 3a 22 31 2e 30 2e 30 22 7d bf**

Report the network status of the device

Network status of device	Description	Status value
Status 1	smartconfig configuration status	0x00
Status 2	AP configuration status	0x01
Status 3	Wi-Fi has been configured, but not connected to the router	0x02
Status 4	Wi-Fi has been configured, and connected to the router	0x03
Status 5	Wi-Fi has been connected to the router and the cloud	0x04

Note:

- When Wi-Fi status of the module changes, Wi-Fi status is sent to MCU.
- Status packet here is used by MCU device to obtain current status of the module. For status 1 and status 2, MCU shall display the network configuration status.
- In principle, you shall adopt two network configuration ways. In the first

network configuration way, a few routers have compatibility issues. The second network configuration way ensures that the device can be connected to the network.

For example, the module sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x02
Data length	2	0x0001
Data	1	Indicates Wi-Fi working status: 0x00: status 1 0x01: status 2 0x02: status 3 0x03: status 4 0x04: status 5
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

For example, the module sends the following command:

55 aa 00 02 00 01 04 06 (the device is connected to the router and the cloud)

MCU returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x02
Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder


MCU returns the following command:

55 aa 00 02 00 00 01

Reset Wi-Fi

Note:

- Status transfer of resetting Wi-Fi is shown as follows:



MCU sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x03
Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

MCU sends the following command:

55 aa 00 03 00 00 02

The module returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x03
Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

The module returns the following command:

55 aa 00 03 00 00 02

Reset Wi-Fi and select configuration mode

Note:

- Compared to "Reset Wi-Fi", with this frame, MCU can select the required configuration mode after the Wi-Fi is reset.
- You can implement this protocol selectively.

MCU sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x04
Data length	2	0x0001
Data	1	0x00: enter smartconfig configuration mode 0x01: enter AP configuration mode
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

MCU sends the command to the control module and enters AP configuration mode:

55 aa 00 04 00 01 01 05

The module returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x04
Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

The module returns the following command:

55 aa 00 04 00 00 03

Report the real-time status


Scenario: If a device has an alert function and requires real-time notification, you can use this command to report the relevant status data.

Note: When MCU needs to report real-time status data, this protocol can be used to report the data.

- Status data is directly reported to the cloud, so the device shall be connected to the cloud already. Otherwise, the device fails to report the data.
- This command is a synchronous command. MCU reports the data, and then waits for the result returned by the module. The waiting timeout is 7 seconds.

- The module sends a network status packet that the server is connected, and then MCU sends the required statistical data packet. The data uploading here does not have storage function. After a period, if the MCU does not receive the network status packet that the server is connected, the MCU will still power off the device. The waiting period is affected by the network and whether it is the first network configuration.
 - If it is the first network configuration, it takes much time to transfer from status 3 (Wi-Fi has been configured) to status 5 (cloud connection status), because the device shall be activated and initialized. It takes a longer time if the network is poor, so it is suggested that the waiting period should be 120 seconds.
 - If it is not the first network configuration, that is, the network has already been configured, it is suggested that the waiting period should be 30 seconds, considering that a longer waiting period is required in case of poor network.
- Support the reporting of multiple data units and single data unit. You can select the packet sending mode as needed. For specific data packet, see the following example.

The general flowchart is shown as follows.



MCU sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00

Command word	1	0x05
Data length	2	It depends on the type and number of the status data unit
Data	N	One or multiple combined "status data unit" groups
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

The module returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x05
Data length	2	0x0001
Data	1	0x00: success 0x01: failure
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

Example of reporting "single status data unit":

The DP of 109 is a Boolean type variable, and the value is 1.

55 aa 00 05 00 05 6d 01 00 01 01 79

Example of reporting "multiple status data units":

The DP of 109 is a Boolean type variable, and the value is 1.

The DP of 102 is a string type variable, and the value is an ASCII code of "201804121507".

55 aa 00 05 00 15 6d 01 00 01 01 66 03 00 0c 32 30 31 38 30 34 31 32 31 35 30 37 5d

Report the record type status (with record storage function)


Scenario: A door lock contains multiple data point data, which shall be processed by the server as one record. In case of transient network failure, the data that cannot be reported will be saved through this command. This command can report the status of record type devices.

Note: When MCU requires the whole data that combines multiple data point and that shall be reported as a whole, this command can be used to send the data to Wi-Fi module. If the device is disconnected from network when the data is being reported, the module will save the data. During the next data transmission, the module will upload the data, and report it together with previously saved data.

- Each time when a previously saved record is reported successfully, the module will send a reply packet in which the command word is 09 and the data is 01. According to the returned packet, MCU will determine it as timeout, and power off. When a record is sent, MCU will wait for 7 seconds. If no reply is received from the module, it is determined that an exception occurs, and the module will be powered off.

- With a normal network, the module connects the server 4 seconds after the module is powered on. When a record is generated and the device is powered on, wait the Wi-Fi module to send the device network status packet as described in the protocol. The waiting period is affected by the network and whether it is the first network configuration.
 - If it is the first network configuration, it takes much time to transfer from status 3 (Wi-Fi has been configured) to status 5 (cloud connection status), because the device shall be activated and initialized. It takes a longer time if the network is poor, so it is suggested that the waiting period should be 120 seconds.
 - If it is not the first network configuration, that is, the network has already been configured, it is suggested that the waiting period should be 30 seconds, considering that a longer waiting period is required in case of poor network. If the packet that the module has been connected to the server is not received when the waiting period expires, this command will be reported. After MCU reports the data, MCU will wait for the reporting results returned by the module.
- Maximum length of data area reported in one record (multiple status data units) is 80. The finally combined and actually saved data length might change, depending on the actual data point. When no network is available, in case of exceeding the stipulated length, Wi-Fi module will return the result that the record cannot be sent.
- Maximum 20 historical records can be saved by the module. In case of exceeding the limit, the earliest records will be overwritten.
- The push is successful (00) when the Wi-Fi module receives a packet that a piece of data is successfully pushed, or if network is unavailable, the record is stored in the flash. When there is a successful push and a delay record, it will return 01. In other cases, it will return 02 to represent the push failure.
- Time data: When the server displays data uploading time, the local uploading time shall prevail. When sending data, MCU also sends local time data, sets the Data[0] time flag bit in the local time protocol to be 1, and transfers data as required by the protocol. When the Wi-Fi module detects that the time flag bit is 1, the time that is transferred by MCU shall prevail (**make sure that time data is correct**).

The general flowchart is shown as follows.



MCU sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa.
Version	1	0x00.
Command word	1	0x08.
Data length	2	It depends on the type, number type and number of the status data unit.
Data	7	Data length is 7 bytes: Data[0] shows whether the data transfer has a local time flag bit. 0 means that the data does not have local time, and the time module thinks that the data is invalid and does not process it. 1 means that the time data is valid. Data[1] is the year, and 0x00 represents the year 2000. Data[2] is the month, ranging from 1 to 12. Data[3] is the date, ranging from 1 to 31. Data[4] is the hour, ranging from 0 to 23. Data[5] is the minute, ranging from 0 to 59. Data[6] is the second, ranging from 0 to 15.
	N	One or multiple combined "status data unit" groups.
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder.

The module returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa.
Version	1	0x00.
Command word	1	0x08.
Data length	2	0x0001.
Data	1	0x00: Reported successfully. 0x01: The current record is reported successfully, and previously saved records need to be reported. 0x02: Failed to report.
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder.

- Example of reporting "single status data unit":

DP 109, Boolean variable, and the value is 1.

55 aa 00 08 00 0c 01 12 04 13 0d 03 1d 6d 01 00 01 01 da //Local time shall prevail.

55 aa 00 08 00 0c 00 12 04 13 0d 04 14 6d 01 00 01 01 d1 //Server time shall prevail.

- Example of reporting "multiple status data units":

- The DP of 109 is a Boolean type variable, and the value is 1.

- The DP of 102 is a string type variable, and the value is an ASCII code of "201804121507".

55 aa 00 08 00 1c 00 12 04 13 0d 06 04 6d 01 00 01 01 66 03 00 0c 32 30 31 38 30 34 31 32 31 35 30 37 a7 //Server time shall prevail.

55 aa 00 08 00 1c 01 12 04 13 0d 08 2e 6d 01 00 01 01 66 03 00 0c 32 30 31 38 30 34 31 32 31 35 30 37 d4 //Local time shall prevail.

Send module command

Note:

"Send command" is an asynchronous processing protocol. When the MCU receives the control packet, it responds to the module about the reception and controls the device according to the command. The MCU status response is shown in the status reporting of the MCU.

For example, the module sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x09

Data length	2	It depends on the type and number of the "command data unit"
Data	N	See the "Status data unit" section
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

The module sends the control command: (The system switch corresponds to DP 3, uses Boolean data type, and the value of 1 indicates power-on)

55 aa 00 09 00 05 03 01 00 01 01 13

Response from the MCU:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x09
Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

ACK response from the MCU:

55 aa 03 09 00 00 0b

Obtain the local time

Note:

- Start to send a data packet to obtain the local time, after the device is connected to network, that is, the device receives status 5 through the command of "reporting the network status of the device".
- After the device is connected to the server, if the network performance is poor, it might fails to obtain time data. Regarding time-dependent devices, such as locks, if local time is not calibrated and it fails to obtain time data, it is required to obtain the time value every 3 seconds, in order to obtain time data successfully.

MCU sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x06
Data length	2	0x0000

Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

MCU obtains local time:

55 aa 00 06 00 00 05

The module returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa.
Version	1	0x00.
Command word	1	0x06.
Data length	2	0x0008.
Data	Data	Data length is 8 bytes: Data[0] shows whether the time is obtained successfully. 0 represents failure, and 1 represents success. Data[1] is the year, and 0x00 represents the year 2000. Data[2] is month, ranging from 1 to 12. Data[3] is the date, ranging from 1 to 31. Data[4] is the hour, ranging from 0 to 23. Data[5] is the minute, ranging from 0 to 59. Data[6] is the second, ranging from 0 to 59. Data[7] is the week, ranging from 1 to 7, and 1 represents Monday.
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder.

The module returns local time data:

55 aa 00 06 00 08 01 12 09 11 10 09 05 01 59

The preceding example represents the local time of Monday, September 17, 2018, 16:09:05.

- If the device is activated and used inside China, local time is Beijing Time (UTC+8).
- If the device is activated and used outside China, local time is the time of the time zone where the device is located.

Wi-Fi functional test

Note:

- Scan the specific SSID: **tuya_mdev_test**, and return the scan result and signal strength percentage.
- Production test command shall be sent after Wi-Fi module is powered on and initialized. That is, the data packet of querying product information is replied. Otherwise, the production test fails or has no result.
- This command is mostly used for testing the finished product during mass production. There is no restriction on password setting of the production test router. But the bandwidth of the router must be 2.4G.

MCU sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa

Version	1	0x00
Command word	1	0x07
Data length	2	0x0000
Data	Data	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

MCU triggers functional test of the module:

55 aa 00 07 00 00 06

The module returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa.
Version	1	0x00.
Command word	1	0x07.
Data length	2	0x0002.
Data	2	Data length has 2 bytes. Data[0]: 0x00 means failure, and 0x01 means success. When Data[0] is 0x01, which means success, Data[1] is signal strength (0-100, 0: the weakest signal, and 100: the strongest signal). When Data[0] is 0x00, which means failure, if Data[1] is 0x00, the designated SSID is not found. If Data[1] is set to 0x01, the module has not generated an authorization key.
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder.

The module returns test results:

55 aa 00 07 00 02 01 50 59

Wi-Fi functional test is successful, and signal strength is 80.

Firmware upgrade

Request to upgrade the Wi-Fi module firmware

Note:

The power-on and power-off of Wi-Fi module are controlled by MCU. To upgrade the Wi-Fi module firmware, MCU can send the following command to obtain the latest firmware.

According to the reply packet of the Wi-Fi module, MCU motherboard determines whether the Wi-Fi module shall be powered off.

- When MCU sends **0a** command, but receives no reply after 5 seconds, MCU powers off the Wi-Fi module.
- When the module replies that firmware is being upgraded, MCU must monitor the upgrading time.
- If MCU does not receive a response of successful firmware upgrading within 60 seconds, it is considered that the firmware upgrading fails and the Wi-Fi module needs to be powered off.

MCU sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x0a
Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

MCU requests to upgrade Wi-Fi firmware

55 aa 00 0a 00 00 09

The module returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x0a
Data length	2	0x0001
Data	1	0x00: (start to detect firmware upgrading) do not power off 0x01: (the latest firmware already) power off 0x02: (upgrading the firmware) do not power off 0x03: (the firmware is upgraded successfully) power off 0x04: (failed to upgrade the firmware) power off
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

Return the module upgrading status:

55 aa 00 0a 00 01 00 0a: it is responded immediately after receiving the upgrading request packet.

55 aa 00 0a 00 01 01 0b: indicates that there is no firmware to upgrade after querying the server.

Request to upgrade the MCU firmware

Note:

- When MCU receives the response from the module that the firmware is upgraded, it means that MCU upgrade file at the service end has been obtained completely, and data transmission has been completed through serial port. After MCU receives the whole upgrade file, and confirms that the obtained file is correct, the module will send query information again. MCU returns the relevant product information, and fills in the new software version number at the server background.
- At present, maximum 480K MCU file can be transferred through Over-the-Air Technology (OTA).

- On the Tuya official website, MCU upgrading method can be configured to app silent upgrade.

MCU sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x0c
Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

MCU requests MCU firmware upgrading:

55 aa 00 0c 00 00 0b

The module returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x0c
Data length	2	0x0001
Data	1	0x00: (start to detect firmware upgrading) do not power off 0x01: (the latest firmware already) power off 0x02: (upgrading the firmware) do not power off 0x03: (the firmware is upgraded successfully) power off 0x04: (failed to upgrade the firmware) power off
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

Return the module upgrading status:

55 aa 00 0c 00 01 00 0c: it is responded immediately after receiving the upgrading request packet.

55 aa 00 0c 00 01 01 0d: indicates that there is no firmware to upgrade after querying the server.

Notification of MCU upgrade packet size

Note:

When MCU receives an upgrade startup packet, the upgrade file size can be known. The module starts to obtain MCU upgrade packet from the service end, and then send the relevant data packet that is transmitted by the upgrade packet.

For example, the module sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x0d
Data length	2	0x0004
Data	4	The number of bytes of firmware packet, the data type is an unsigned integer, and the data storage is in big-endian mode
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

The module sends file packet size:

55 aa 00 0d 00 04 00 00 68 00 78: the size of firmware packet is 26624 bytes, namely 26 KB.

MCU returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x0d
Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

ACK response from the MCU:

55 aa 00 0d 00 00 0c

Upgrade packet transmission

Note:

- The data format of upgrade packet transmission: packet offset (unsigned short) + packet data.
- If MCU receives the frame with data length equal to 4 and the upgrade packet offset is equal to or greater than the size of firmware, the packet transmission ends.

For example, the module sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa.

Version	1	0x00.
Command word	1	0x0e.
Data length	2	The data length is the sum of 0x0004 and the data packet length.
Data	N	The first 4 bytes are fixed as packet offset, and the latter bytes are the packet content.
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder.

The module sends file data:

If the file to be upgraded has 530 bytes, under this circumstance, the MCU can skip the response for the last data packet.

1. For the first packet data, packet offset is 0x00000000, and data packet length is 256.

55aa 00 0e 0104 00000000 xx...xx XX

2. For the second packet data, packet offset is 0x00000100, and data packet length is 256.

55aa 00 0e 0104 00000100 xx...xx XX

3. For the third packet data, packet offset is 0x00000200, and data packet length is 18.

55aa 00 0e 0016 00000200 xx...xx XX

4. For the last packet data, packet offset is 0x00000212, and data packet length is 0.

55aa 00 0e 0004 00000212 xx...xx XX

MCU returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x0e
Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

Confirm each data packet of MCU:

55 aa 00 0e 00 00 0d

Query the signal strength of the currently connected router

Note:

With this command, query the signal strength of the router that is connected to the device currently. The precondition is that device network status packet is received, and the device is connected to the router successfully. Otherwise, the failure result will be returned.

MCU sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x0b
Data length	2	0x0000
Data	0	None
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

MCU obtains the strength of the connected router:

55 aa 00 0b 00 00 0a

The module returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa.
Version	1	0x00.
Command word	1	0x0b.
Data length	2	0x0002.
Data	2	Data length has 2 bytes. Data[0]: 0x00 means failure, and 0x01 means success. When Data[0] is set to 0x01, which means success, Data[1] is signal strength (0-100, 0: the weakest signal, and 100: the strongest signal). When Data[0] is 0x00, which means failure, if Data[1] is 0x00, the device fails to connect the router.
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder.

Module returns current value of strength (80):

55 aa 00 0b 00 02 01 50 5D

Obtain DP cache command

Note:

For the sensors with setting or control features, DP sending function shall be added. If a panel sends a command when the device is offline, the command is cached in the cloud. The device will obtain it later. The cache command is incremental mode. The obtained commands will not be sent again next time.

MCU sends the following command:

Field	Length (byte)	Description
Header	2	0x55aa
Version	1	0x00
Command word	1	0x10
Data length	2	N
Data	dp_num(1byte) + dp_1(byte) +...+ dp_n(1byte)	If dp_num is 0, it will query all the DPs
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder

The lock obtains the cache command of dp115, dp114, and dp113:

55 AA 00 10 00 04 03 73 72 71 6C

The module returns the following command:

Field	Length (byte)	Description
Header	2	0x55aa.
Version	1	0x00.
Command word	1	0x10.
Data length	2	It depends on the type and number of the "status data unit".
Data	result(1byte) + dp_num(1byte) + dp_1(byte) +...+ dp_n(1byte)	<p>"Status data unit" group, return DP data with cache command. Result: it indicates whether the command is obtained successfully.</p> <p>Result 0 means failure. DP data will not be indicated, and data content length is 1.</p> <p>Result 1 means success.</p> <p>dp_num: If dp_num is 0, it is considered that there is no cache command currently.</p>
Checksum	1	Start from the header, add up all the bytes, and then divide the sum by 256 to get the remainder.

The module returns the following data, which means to lock the door after 30 seconds.

55 AA 00 10 00 14 01 03 73 01 00 01 01 72 04 00 01 01 71 02 00 04 00 00 00 1E AA

- DP115 is automatic lock, Boolean type, meaning to close the door automatically or not.
- DP 114 is delayed lock selection, enumeration type, meaning to lock the door at once or continue timing.
- DP 113 is numeric type, and the unit is second.

Communication protocol – Functional protocol

Communication protocol (product functions) command send-receive table

ID	Function name	Header version	Command word	Data length	dpID	Data type	Function length	Function command	Checksum
----	---------------	----------------	--------------	-------------	------	-----------	-----------------	------------------	----------

1	Door Sensor	MCU report	0x55aa 0x00	0x05	0x00 0x 05	0x01	0x01	0x00 0x 01	off:0x0 0 on:0x01	Checksum
3	Battery level state	MCU report	0x55aa 0x00	0x05	0x00 0x 05	0x03	0x04	0x00 0x 01	low:0x0 0 middle: 0x01 high:0x 02	Checksum